

Boafeng disable PTT for out of band Frequencies.txt  
How to diasable transmitting on a given frequency

Using Chirp Program

On frequencies that are out band:

Set the duplex to "OFF"  
Set the offset to "0.0000 MHz"  
Set power level to "L"

Upload the changes to the radio.  
Save the setting on your computer.